



We suggest changing the bottom. Instead of placing the bottom inside the walls, hinge the bottom for cleaning purposes.

1" X 10" CEDAR  
HOLE: 1 3/4" FROM TOP

NEEDED: 8' BOARD/BOX  
2 7/8" HOLE (STYROFOAM SUP) 1 3/4" FROM TOP